



BARTLETT Instrument Company

Help Find A Solution With This Simple Troubleshoot!

[Home](#) • [Controller Overview](#) • [V6CF](#) • [RTC1000](#) • [3Key](#)



There are some helpful hints to know when running your kiln with a Bartlett controller. If you'd like to monitor when the relays turn on or off during the firing, press the 8 key. If the relays are turned on, three dots will appear along the bottom of the display.

In a 3-zone kiln, the left light is for the top section, the middle light for the middle section, and right light for the bottom section.

When the relays are turned on, they power the heating elements of the kiln. This feature can be especially helpful during diagnostics.

The controller adjusts the kiln temperature during a firing by sending power to the relays intermittently. If there is a problem with power getting to the elements or the relays, this is a good place to start looking.

You may have to wait a few minutes if the controller is not currently sending power to the relays. If the dots appear in the display, the controller is sending power to the relays, you can begin eliminating it as the source of the problem. If you've got questions you can always give us a call at 1-888-404-9026.



Got topics you'd like to see covered or art pieces you'd like to share? Respond to this email and let us know!

BARTLETT

Instrument Company

1032 Avenue H

Fort Madison, IA 52627

Phone: 1(888)404-9026 Fax: (319)372-5560

www.bartinst.com