



***BARTLETT*** Instrument Company

# No Wiring Needed For The Wind/Rain Alarm To Close Vents!

[Home](#) • [Controller Overview](#) • [GHK](#) • [RWL](#) • [CIS](#) • [W/R Alarm](#)

With improvements always on our mind, we've made some upgrades to our CIS software this year. It will still have all its great features, but we've added some new capabilities for the Wind/Rain Alarm in CIS. You will no longer need to wire the W/R Alarm to each controller to allow it to close vents in the event of bad weather.

Now, with a few simple settings in the CIS program, the W/R Alarm can override all of your vents without any extra wiring. When high winds or rain comes along, CIS will close all of your vents to Percent 1 for you and return them to their previous settings when the wind or rain alarm is no longer active.

Enabling the W/R Alarm control on the new CIS software is easy:

- First, ensure that Enable Weather Sensor is checked in the Preferences Menu under the Options tab.
- Next, select one of the controllers whose vents will be controlled by the W/R Alarm.
- Click on the Menu tab.
- Then, at the bottom in the Wind/Rain alarm override box, select the vents to be overridden in the event of bad weather. Repeat for each controller to be overridden.
- When a wind or weather alarm occurs, CIS will now automatically close the vents to your first percentage if they are open.

You'll need to upgrade your current CIS software to Version 1.1.0 to enable this new capability. Contact us to find out how you can get your current CIS 2015 software upgraded to allow for added W/R Alarm control, without the hassle of wiring!

Greenhouse Control

Options About

Prev Selected Controller Name ID Model  
**Greenhouse 2** **2** **RWL11X2**

Next

Greenhouse Name	Status	Z1	Z2	Rel Hum	H1	C1	C2	H2	C3	C4	Tmr	H3	%1	%2	Data
Greenhouse 1	DAY	75		0	OFF	ON	ON	OFF	OFF	OFF	OFF			0	ON
Greenhouse 2	DAY	77	77	0	OFF			OFF		OFF	OFF		99	99	OFF

COM15 is open Communication Rate: 97.4 % No Alarms

Status Statistics Run Times Logs Program Menu

Controller Info  
 Model: RWL11X2 FW: L ID: 2

Name of Greenhouse #2  
 Greenhouse 2

☒ In Use ☐ Not In Use

Times  
 Delay Between Heat/Cool 5  
 On to Auto Time 0:20

Alarms  
 Zone1 Zone2  
 Low Temp 55 32  
 High Temp 131 131

Thermistor Fail Mode  
 HEAT

Log Files  
☒ Log Data by Event Select File +C:\Users\bartlett instrument\Documents\GH2EventLog.cel  
☒ Log Data by Time Select File +C:\Users\bartlett instrument\Documents\GH2TimeLog.cel

Wind/Rain Override  
 Allow Wind/Rain alarm to override current vent setting to ☒ Vent 1  
 Percent 1 setting: ☒ Vent 2

***BARTLETT***  
**Instrument Company**  
 1032 Avenue H  
 Fort Madison, IA 52627  
 Phone: 1(888)404-9026 Fax: (319)372-5560  
[www.bartinst.com](http://www.bartinst.com)

**Get social with us to keep up with  
 our latest deals and tips!**

